

How to permanently prevent leaking showers



CROMMELIN SHOWER WATERPROOFING KIT & SHOWER WATERPROOFING MEMBRANE are permanent solutions to seal wet areas and balconies prior to tiling.

How to permanently prevent leaking showers

SHOWER WATERPROOFING KIT is a complete DIY kit designed to meet the Australian Standard. The kit contains **SHOWER WATERPROOFING MEMBRANE**, a simple to use one-pack product suitable for use with most tile adhesives.



YOU WILL NEED

A 4 litre kit will treat a 2 wall shower recess.

A 6 litre kit will treat a 3 wall shower recess.



EQUIPMENT

No extra equipment needed – the **SHOWER WATERPROOFING KIT** contains all the necessary tools required.



NUMBER OF COATS

2 coats are required and should be applied at 90° to each other.



DRYING TIME

Allow 2 hours drying time between coats.

Suitable to be tiled over after 48 hours.



CLEAN UP

SHOWER WATERPROOFING MEMBRANE is easily cleaned up with water before it dries.



TIPS

Pre-cut reinforcing fabric prior to installing in corners and around drainage outlets.

Do not try to build-up the coating thickness in one coat.

For detailed instructions on suitability, surface preparation and application steps, please refer to the product label.

Should you have any project specific questions or require further product information please do not hesitate to contact us.

Freecall Technical Advice 7 days: 1800 655 711
www.crommelin.com.au

Crommelin
Waterproofing & Sealing



Customers need to undertake their own assessment to determine the suitability of a product for the particular use intended. As the performance of any product is subject to a wide variety of different surface types as well as environmental and surface-specific conditions, it is essential that a sample of the product be applied to the intended area of use to ensure it is acceptable in appearance and finish and that it perform on the specific surface.